



1. Set control rod bell crank (A) in Park position.
2. Set control shaft lever (B) in Park position.
3. With both the bell crank and lever held in Park position, assemble control rod (C) to lever (B), then adjust clevis on rod (C) for easy entry into lever (A).

Linkage Kit Includes:

- # 1 Shift rod (1)
- # 2 Clevis (1)
- # 3 Clevis pin (1)
- # 4 J-clip (1)
- # 5 Cotter pin (1)
- # 6 5/16" washer (1)
- # 7 Nut (1)

PART NO.	YEARS: 1962-64	DATE	REVISION	AUTH.	REVISED BY
271K - POWERGLIDE SHIFTER LINKAGE KIT					
WEB: https://www.paragoncorvette.com/p-356935-powerglide-shifter-linkage-kit.aspx					
GM Part No.	SHEET 1 OF 1				